



REVIEW DRAFT - NOT RELEASED OPERATING INSTRUCTIONS

Cantilever rack

Configuration & care review



AMERICAN
MORTUARY COOLERS
Built for Life's Critical Work.

5T-C

Representative configuration

Premium 5-Tier Cantilever Mortuary Storage Rack

Series: 5T-C. Preserve the exact selected SKU on the quote.

Representative photograph only. Tier count, feet, casters and tray contents must match the accepted configuration. This draft adds no load rating, compatibility claim or engineering approval.



REVIEW DRAFT - NOT RELEASED OPERATING INSTRUCTIONS

Match the configuration

Record exact SKU, tiers, base, tray choice and quantity. Tray width alone does not establish fit. Confirm bearing surfaces, arm spacing, retention, lift approach and transfer heights. Do not assume a caster retrofit is approved.

Receipt and setup

Keep the rack unloaded until approved assembly instructions, fastener schedule, torque requirements and installation acceptance are available. Check shipment, floor, clearances and rack labels. Do not use a competitor drawing as the assembly instruction.

Leveling feet / casters / adjustable arms

Confirm the approved leveling and restraint method for stationary versions. Identify supplied wheels, mounts, brakes and locks for caster versions. Reposition adjustable arms only under the approved unloaded procedure; never loosen supports while a tray is present.

Loading and transfer

Use trained staff and the approved handling procedure. Read the exact per-tier and whole-rack limits, including tray and accessory weight. Confirm tray bearing and retention before transfer. Keep clear of pinch points. Do not infer limits from tier count or another brand.

Movement controls

Casters alone do not authorize loaded transport. Keep the rack stationary until written mobility limits and route review allow the proposed movement. Never use the rack as a ladder or personnel support.

Inspection and care

Before each use, check visible bending, weld damage, loose or missing hardware, tray-contact damage, wheels and brakes. Remove damaged equipment from service. Use only cleaning agents and procedures approved for the actual finish and facility protocol.



REVIEW DRAFT - NOT RELEASED OPERATING INSTRUCTIONS

Configuration acceptance

Complete this record against approved drawings before the guide is released.

Exact SKU / serial number

Tier count / feet or caster base

Per-tier / complete-system limits

Unloaded / loaded movement limits

Tray / bearing surfaces / retention

Floor / clearances / restraint

Lift model / transfer surface heights

Caster model / mounts / brakes

Assembly revision / hardware / torque

Cleaning compatibility / service

Reviewer / date / release signature

Need the approved instructions?

Send the exact model, photos and issue description to

cool@mymortuarycooler.com